

Installation sequence
Figure 1

- Once the general location determined, mark points at the ends of the lower molding.
- Draw a line that is level between the 2 points.
- Using the pre-perforated moulding as a guide, draw benchmarks on the wall.
- Using a concrete drill bit, drill holes and insert the plastic anchors.
- Screw the moulding into place.

Figure 2

- Using the pre-perforated left moulding as a guide and insuring a vertical position, draw benchmarks on the wall.
- Drill holes and screw in place the left moulding.

Figure 3

- Using the pre-perforated top moulding as a guide and insuring parallel position, draw benchmarks on the wall.
- Drill holes and screw in place the top moulding.

Figure 4

- Slide the boards into the mounted moldings.

Figure 5

- The male/female concealed joint holds the boards together.

Figure 6

- Using commercial adhesive, glue the right molding into place.

